

CLEANING INSTRUCTIONS

- Operate the shade daily. The up and down movement will “shake off” most dust preventing build-up. Dusting frequently prevents dust build-up and maintains clarity.
- It is recommended that the shade remain in the brackets or cassette while cleaning to prevent handling and reinstallation of the shade.
- Dust, wipe or dry in a single direction.
- Clean with a soft dry cotton cloth or feather duster. Use a soft 100% cotton cloth along with a cleaning solution to remove fingerprints, spots or greasy residue. Do not use abrasive cleaning or wiping materials such as paper towels, sponges, brushes or brooms.
- Fingerprints and most smudges, spots or greasy residue are easily removed with a mixture of mild detergent diluted with water. Spray an adequate amount of the water solution onto the shade to allow surface cleaning without scratching.
- Shades must not be rolled up after using wet solution to clean before they are absolutely dry.
- Cleaning Solution
 - *Mix a diluted solution of 75 ml dish washing liquid with 500 ml tap water. Isopropyl alcohol (rubbing alcohol) can also be used as a cleaning solution.*
- Do not use window cleaners or other solvents containing ammonia.
- To prevent soap spotting, it is recommended not to clean in bright, hot sunlight.
- Dry the fully extended shade with a soft cotton cloth.
- Re-rolling by other than the use of the chain/cord roll-up device may cause the shade material to crease, dent, and fold or become misaligned.